## Technical Bulletin

Bulletin No. 007 Rev B

Subject: Non-Rain Master Remote Use with RME Sentar and

**RME Hawk** 

Page 1 of 2

Product Applicability: RME Sentar, RME Hawk

Engineering Release: R. A. Olson Engineering Release Date: June 19, 2003

Distribution: APPROVED FOR GENERAL RELEASE

Using a non-Rain Master Remote Unit with the RME Sentar or RME Hawk controllers requires the addition of a 24 VAC transformer. The transformer is available under Rain Master part number TR4.

The proper connection is shown on the attached drawing.


**CAUTION:** 

Before making the connections, place the RAIN SWITCH on the controller to the "NO WATERING" POSITION.

FAILURE TO DO SO MAY CAUSE DAMAGE TO THE REMOTE AND/OR CONTROLLER.



Tel: (805) 527-4498 Fax: (805) 527-2813



## **End of Bulletin**



Sheet 2 of 2

Tel: (805) 527-4498 Fax: (805) 527-2813